

How to maintain and clean your Hideaway™ Bin

Your Hideaway Bin:

- It is recommended you use warm soapy water to clean your Hideaway Bin. Avoid hard abrasive cleaners.
- When cleaning, try to avoid getting the tracks wet, however, if this happens ensure you dry the tracks well and then regrease.
- Over time you may need to lubricate your tracks for continued free movement. To do this, lube with a small amount of petroleum jelly such as Vaseline.
- If your model is fitted with a perfume sachet for odour control you will need to unwrap the plastic from around the sachet. The sachet can be found in the lid of your unit. The perfume sachet should last 2-3 months and replacements can be purchased via our website.

DOWNLOAD FULL INSTRUCTIONS on how to clean and take care of your Hideaway Bin - www.hideawaybins.co.nz & www.hideawaybins.com.au

Alternatively, you can give us a call and we will email or post the instructions to you.

Full Care and Maintenance instructions (model dependant) will cover:

- How to replace perfume sachets.
- How to remove, clean and replace a friction fit lid.



- How to care for, remove and replace tracks for cleaning.

Important information:

- Do not over fill your bin as contents could scratch your friction fit lid.
- Refrain from pushing down on rubbish inside your bucket/s as this creates extra pressure on the fixings inside your carcass.

VERY IMPORTANT - IF YOU HAVE A SOFT CLOSE BIN, YOU MUST ENSURE YOUR TRACKS ARE ENGAGED! REFER TO THE PICTURES IN THE INSTALLATION INSTRUCTIONS BEFORE USING YOUR BIN.

Replacement parts for your Hideaway Bin can also be purchased online!

Questions?

NEW ZEALAND

Phone 09 426 7456

Web www.hideawaybins.co.nz

Email info@hideawaybins.co.nz

AUSTRALIA

Freephone 1800 042 642

Web www.hideawaybins.com.au

Email info@hideawaybins.co.nz

